


**HELUTEK A Series
TWINTEC B**
Mounting instructions

**PLUG HOUSING
TWINTEC B**
Crimping contacts




Helutec® mounting instructions published here are for general information purposes only. All data are subject to change without notice, errors excepted. Helutec® mounting instructions are mandatory, only when supplied together with connectors, components or project related documents. PDF file generated 02/2005.



EXTENSION HOUSING
TWINTEC B
Crimping contacts



Helutec® mounting instructions published here are for general information purposes only. All data are subject to change without notice, errors excepted. Helutec® mounting instructions are mandatory, only when supplied together with connectors, components or project related documents. PDF file generated 02/2005.



**RECEPTACLE HOUSING
STRAIGHT – TWINTEC B**

Crimping contacts



Helutec® mounting instructions published here are for general information purposes only. All data are subject to change without notice, errors excepted. Helutec® mounting instructions are mandatory, only when supplied together with connectors, components or project related documents. PDF file generated 02/2005.

